



DS-KD7000EY Series Module Door Station

Quick Start Guide

UD39405B

Quick Guide

1 Set Physical Address

- 1.1 Door Station/Outer Door Station rotary Switch Settings
- 1.2 Indoor Station rotary Switch Settings

2 Wiring

- 2.1 System wiring
- 2.2 Wiring

3 Installation


- 3.1 Before you start
- 3.2 Installation position
- 3.3 Flush mounting and surface mounting

4 Power On


Power on and start operation.

Appearance and Interface


1. The pictures here are for reference only.
2. The nametag can be replaced.



1. Adjust Loudspeaker/Mic




2. AP Mode




You can check the AP mode password (Access Code) via the label on the surface of the device.

3. Pairing and Synchronization



4. Reset



About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED AND ILLEGAL DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.


1 Set Physical Address

Door Station

Use the rotary switch to set the building No., door station No., sub door station, outer door station No. and door open duration. The Tens column refers to the number in Tens, and the Units column refers to the number in Units. On each rotary switch, 0 to 9 refers to No. 0 to 9.

In total, you can use 1 to 99 to number the building.
If the door station is main door station, the **Door Station No.** should be set as 0; If it is sub door station, set **Door Station No.** as 1~16; If it is outer door station, set **Door Station No.** as 90~99. Use the screwdriver to adjust the number. The arrow indicates the number.

For example:



Rotary Switch	Door Open Duration(s)
0	2
1	1
2	3
3	4
4	5
5	8
6	10
7/8/9	Reserved

It is recommended to stick the supplied number remark on the back of the device to indicate the device's No.

Indoor Station

No. Settings

Use the rotary switch to set the indoor extension No., the building No., and the room No. The Hundreds refers to the number in Hundreds, the Tens refers to the number in Tens, and the Units refers to the number in Units.

On each rotary switch, 0 to 9 refers to No. 0 to 9. In total, you can use 1 to 3 to number the indoor extension No., 1 to 99 to number the building, and 1 to 400 to number the room.

Use the screwdriver to adjust the number. The arrow indicates the number.

Device Mode Settings

Use the rotary switch to set the indoor station's device mode according to actual scenarios.


Villa Mode: Under the villa mode, the device needs to be powered by 12 VDC power supply. More than one device can light up the screen; when the extension is called, the screen can light up and allow video call.

Building Mode: In one power supply system, up to 3 indoor extensions can be wired to 1 one main indoor station. When the screen of other devices lights up, the *IN USE* indicator will also lights up. Devices cannot be powered by separate power supply. When the indoor extension is called, the screen will not light up.




- DIP 1 and DIP 2 are for mode settings, and DIP 3 and DIP 4 are reserved.
- If DIP 2 is set as **1**, the function of **Professional Studio** can be set.
- The device is on debugging mode when the extension No. is 9. You can operate the indoor station on debugging mode without connecting to the door station.

For example:




2.1 System Wiring



2.2 Wiring

Scan the QR code to get User Manual for details.



Cable Type Description

Cable Type	DS-KAD7060EY to Door Station	DS-KAD7060EY to DS-KAD7061EY	DS-KAD7061EY to DS-KAD7061EY	DS-KAD7061EY to Indoor Station	Indoor Station to Indoor Station	DS-KAD7060EY to DS-KAD7060EY-S	Indoor Station to Door Station
UTP 5 0.2 mm ² (Cat.5) AWG24	60 m	60 m	60 m	60 m	100 m	60 m	140 m
0.28 mm ² (TP) AWG23	60 m	40 m	40 m	40 m	80 m	40 m	160 m
0.5 mm ² (parallel) AWG20	60 m	60 m	60 m	60 m	100 m	60 m	180 m
1 mm ² (parallel) AWG17	60 m	60 m	60 m	60 m	100 m	60 m	260 m
1 mm ² (TP) AWG17	60 m	40 m	40 m	40 m	80 m	40 m	260 m
1.5 mm ² (parallel) AWG15	60 m	40 m	60 m	60 m	100 m	60 m	260 m

3 Installation


Note: Video intercom module door station supports flush mounting and surface mounting. You can install module door station through one-module frame, two-module frame and three-module frame. Here takes three-module frame installation as an example.

Before You Start


- Tools that you need to prepare for installation: Drill(6), cross screw driver (PH1*150mm), and gradienter.
- Make sure all related equipments are power-off during the installation.
- Make sure you have configured the sub module address before installation. Valid sub module address ranges from 1 to 20. The No. should be unique for sub modules that connected to the same door station. The figure below shows an example of sub module address and corresponding DIP switch status.

Sub Module No.	DIP Switch 1	DIP Switch 2	DIP Switch 3	DIP Switch 4	DIP Switch 5	DIP Switch 6	DIP Switch 7	DIP Switch 8
Module 1	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Module 2	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
Module 3	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
Module 4	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
Module 5	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
Module 6	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
Module 7	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
Module 8	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF

Flush Mounting



Surface Mounting



4 Configuration

1. Configuration and Management via Mobile Web

Enable AP Mode→Login

- Long press the button on the left side of the device for 10 s to enable the AP mode.
- Connect your mobile devices to the device hotspot. Enter the device user name and AP mode password. Tap **Login**.

You can check the AP mode password (Access Code) via the label on the surface of the device.

2. Call Indoor Station from Door Station/Outer Door Station/Sub Door Station

- Set physical address for indoor station and door station/outer door station/sub door station via the rotary DIP switch.
- Connect the indoor station and door station/outer door station/sub door station.
- Call indoor station from door station/outer door station/sub door station.

For more details about the configuration, please refer to the *User Manual*.



Installation Position

Recommended Installation Height (The distance between the camera and the ground): 1.4 m to 1.6 m
The FOV of the camera is : Horizontal: 133°, Vertical: 82°.
The highest visual height and lowest visual height of the camera is shown as picture.

