

English

1 APPEARANCE

1. Indicator
2. Extension Cable
3. Tamper Button
4. Probe
5. Learn button

2 ENROLLMENT

3 INSTALLATION

- I. Check signal strength.
 - II. Install the detector.
 - a. Stand mounting
 - b. Wall mounting
1. with screws
 2. with sponge tape

4 TEST

- a. Stand mounting test
- b. Wall mounting test






User Manual

Scan the QR code for more information and operation help.

Specification

Installation	Wall mount/Direct touch
Tamper protection	Front & Back
LED indicator	Blue (alarm)
Operating temperature	-10 °C to 55 °C (14 °F to 131 °F)
Storage temperature	-20 °C to 60 °C (-4 °F to 140 °F)
Operating humidity	10% to 90%
Water protection	IP66
Dimension (H x W x D)	62.4 mm x 62.4 mm x 14.6 mm
Weight	85.5 g
Transmission frequency	433 MHz
RF range	1.2km (free space)
Battery	CR2450 x 1 (included)
Standard battery life	3 years

©2024 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.
About this Manual
This Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (<https://www.hikvision.com/>).
Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.
HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned are the properties of their respective owners.
Disclaimer
TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INJECTION, OR OTHER INTERNET SECURITY RISKS. HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW, ESPECIALLY YOU ARE RESPONSIBLE FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OR MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSION OR UNLAWFUL NUCLEAR FUEL CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATTER PREVAILS.



User Manual



Español

1 APARIENCIA

1. Indicador
2. Cable de extensión
3. Botón antimanipulación
4. Sonda
5. Botón de memoria

2 REGISTRO

3 INSTALACIÓN

- I. Comprobar la intensidad de la señal.
 - II. Instale el detector.
 - a. Montaje en soporte
 - b. Montaje en pared
1. con tornillos
 2. con espuma autoadhesiva

4 PRUEBA

- a. Prueba de montaje en soporte
- b. Prueba de montaje en pared

Manual de usuario

Escanee el código QR para obtener más información y ayuda sobre el funcionamiento.

Especificación

Instalación	Montaje en pared/pulsación directa
Protección antimanipulación	Anterior y posterior
Piloto led	Azul (alarma)
Temperatura de funcionamiento	-10 °C a 55 °C (14 °F a 131 °F)
Temperatura de almacenamiento	-20 °C a 60 °C (-4 °F a 140 °F)
Humedad de funcionamiento	10 % a 90 %
Protección contra el agua	IP66
Dimensiones (alto x ancho x fondo)	62,4 mm x 62,4 mm x 14,6 mm
Peso	85,5 g
Frecuencia de transmisión	433 MHz
Alcance de radiofrecuencia	1,2 km (espacio abierto)
Batería	1 batería CR2450 (incluida)
Vida útil de la batería convencional	3 años

Slovenščina

1 PREGLED NAPRAVE

1. Indikator
2. Podaljšek
3. Gumb za nedovoljene posege
4. Sonda
5. Gumb za pomnjenje

2 VPIS

3 NAMESTITEV

- I. Preverite moč signala.
 - II. Namestite detektor.
 - a. Samostojna namestitve
 - b. Stenska namestitve
1. z vijaki
 2. s penastim trakom

4 PREIZKUS

- a. Test pri samostojni namestitvi
- b. Test pri stenski namestitvi

Uporabniški priročnik

Če želite več informacij in pomoč pri delovanju, optično preberite kodo QR.

Tehnični podatki

Namestitev	Stenska namestitev/neposredni dotik
Zaščita pred nedovoljenimi posegi	Spreddaj in zadaj
Indikator LED	Modri (alarm)
Temperatura delovanja	-10 °C do 55 °C (14 °F do 131 °F)
Temperatura skladiščenja	od -20 °C do 60 °C (od -4 °F do 140 °F)
Vlažnost za delovanje	Od 10 do 90 %
Zaščita pred vodo	IP66
Dimenzije (V x Š x G)	62,4 mm x 62,4 mm x 14,6 mm
Teža	85,5 g
Frekvenca oddajanja	433 MHz
RF-razpon	1,2 km (v prostem prostoru)
Baterija	CR2450 x 1 (priložena)
Standardna življenjska doba baterije	3 leta

Português (Brasil)

1 APRESENTAÇÃO

1. Indicador
2. Cabo de extensão
3. Botão de violação
4. Fiscalização
5. Botão Aprender

2 REGISTRO

3 INSTALAÇÃO

- I. Verifique a intensidade do sinal.
 - II. Instale o detector.
 - a. Montagem em suporte
 - b. Montagem na parede
1. com parafusos
 2. com fita de espuma

4 TESTE

- a. Teste de montagem em suporte
- b. Teste de montagem na parede

Manual do usuário

Leia o código QR para mais informações e ajuda na operação.

Especificações

Instalação	Montagem na parede/toque direto
Proteção antivolação	Frontal e traseira
Indicador LED	Azul (alarme)
Temperatura de operação	-10 °C a 55 °C
Temperatura de armazenamento	-20 °C a 60 °C
Umidade de operação	10% a 90%
Proteção contra água	IP66
Dimensões (A x L x P)	62,4 mm x 62,4 mm x 14,6 mm
Peso	85,5 g
Frequência de transmissão	433 MHz
Faixa de RF	1 x CR2450 (incluída)
Bateria	1 x CR2450 (incluída)
Duração padrão da bateria	3 anos

Srpski

1 IZGLLED

1. Indikator
2. Produžni kabl
3. Dugme za neovlašćene izmene
4. Sonda
5. Dugme za uparivanje

2 UVŠTAVANJE

3 INSTALACIJA

- I. Proverite jačinu signala.
 - II. Instalirajte detektor.
 - a. Postavljanje na stalak
 - b. Postavljanje na zid
1. koristeći vijke
 2. koristeći sunderastu lepljivu traku

4 TEST

- a. Ispitivanje montaže na stalak
- b. Ispitivanje montaže na zid

Korisnički priručnik

Skenirajte QR kôd za više informacija i pomoć prilikom rada.

Specifikacija

Instalacija	Postavljanje na zid / Direktan dodir
Zaštita od neovlašćenih izmena	Napred i pozadi
LED indikator	Plavo (alarm)
Radna temperatura	Od -10 °C do 55 °C
Temperatura skladištenja	Od -20 °C do 60 °C (od -4 °F do 140 °F)
Radna vlažnost	Od 10 % do 90 %
Zaštita od vode	IP66
Dimenzije (V x Š x D)	62,4 mm x 62,4 mm x 14,6 mm
Težina	85,5 g
Frekvenca prenosa	433 MHz
RF opseg	1,2 km (slobodan prostor)
Baterija	CR2450 x 1 (uključena)
Standardni radni vek baterije	3 godine

