



HIKVISION



Wireless Router


Quick Start Guide

Packing List



Place the Router

- The closer, the faster.
- Higher and no coverage.
- Place it on the centre to cover more space.



More Information


Get more information about configuring the device by scanning the QR code beside or going to <https://enpinfodata.hikvision.com/analysisQR/showQR/3fe6bd89>



1

Learn About Router


Descriptions about indicators and interfaces.



- Solid Blue:
The Internet is accessible.
- Flash Blue:
Device pairing or restoring to defaults...
- Solid Red:
Unactivated or the Internet is inaccessible;
Or upgrading...
- Flash Red:
Device pairing or broadband migrating...

Connect to downlink devices
(e.g. IPCs, PCs).

LAN



WPS/RST

Long press for 1-3s:

- Password-free accessed by wireless devices;
- Mesh networking with Hikvision routers.

Long press for 8s:

- Restore to defaults.

WAN/LAN

Connect to an uplink device
(e.g. modem).

POWER



Connect to the power supply adapter.

2

Connect Power Supply and Internet


Refer to the figures below to complete wiring.

Connect to the Internet



Ethernet Cable

Connect to Power Supply



3


Activate Router

Follow these steps to complete the initial activation of the router.

Check the Label


Obtain Wi-Fi name and IP address.

Wi-Fi Name(SSID): HIKVISION_XXXX
IP Address: 192.168.9.1
Login Address: <http://hikrouter.net>



Connect to a Wi-Fi Network


Connect your device to the Wi-Fi.



Enter Activation Page

Automatically redirect to the page.

Select your Country/Region



If not, you can manually enter IP address (**192.168.9.1**) or login address (**<http://hikrouter.net>**) in the browser.

A


Create New Wi-Fi

Your router will work independently and create a new Wi-Fi network.

Start Initial Configuration




Select **Router Mode** and follow the steps below to complete the configuration.

1. Device Connection



Make sure the router is connected to the network.

2. Network Config: Detect your network type or select manually.




3. Route Settings



- Set Wi-Fi password -- For connecting the Wi-Fi
- Set Admin password -- For managing the device

NOTE: Please check more information about VLAN and VPN on the User Manual.




Completed

Wi-Fi will restart.

B

Extend Wi-Fi Range by Mesh

Quick activate the sub router and expand Wi-Fi coverage of the main router.



[Steps]

1. Power on **B** and place it near **A**. The indicator on **B** is solid red.
2. Press the WPS/RST buttons on both **A** and **B** for 1-3 seconds. Wait until the indicator on **B** is solid blue.
3. Disconnect the power supply on **B**, and place it in the location where Wi-Fi coverage needs to be expanded.
4. Reconnect **B** to the power supply. Wait until the indicator on **B** is solid blue again.


[Note]

- The Wi-Fi names and passwords of A and B are the same.
- If step 2 is failed, try to connect a LAN port of **A** and the WAN port of **B** by an Ethernet cable, and repeat the next steps after the indicator on **B** is solid blue.


^① Please refer to the **More Information** and get methods for devices that do not support Mesh.

[Before You Start]

- Ensure that both routers support Mesh.
- Ensure that **A** can access the Internet normally.
- Ensure that **B** is unactivated (long press the WPS/RST button for 8s to restore if it has been activated).



The Indicator is Solid BLUE



Reconnect to the Wi-Fi after status checking.

Enjoy fast and smooth surfing !



Manage Your Router Anytime, Anywhere

1. Download Apps

Scan the QR code below to download the apps. Both the apps can help you manage your device remotely.



2. Open an App and Login

Create a new account to login if you don't have one before.

3. Add Device

Scan the QR code on the label of the router, and follow the steps on the APP to complete the setup.



See Far, Go Further

UD41654B

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.